














PLANET
ACCESSORIES AND SPARE PARTS

	DESCRIPTION	Ø	REF.	USE
	GALVANIZED STEEL REDUCER CUFF	40	VP06851	Connecting the flexible tube to the vacuum cleaners inlet Ø 70
	GALVANIZED STEEL REDUCER CUFF	50	VP06852	
	GALVANIZED STEEL CUFF	40	VP07247	End-join. It is used to connect the anti-static flexible hose to the aluminium inlet Ø 60
	GALVANIZED STEEL CUFF	50	VP07461	
	STAINLESS STEEL CUFF	40	VP06882	End-join. It is used to connect the anti-static flexible hose to the accessories.
	GALVANIZED STEEL CUFF 58/60 JOIN	60	VP07273	Used to connect the flexible hose to the aluminium inlet Ø 60
	GALVANIZED STEEL CUFF 58/75 JOIN	60	VP07272	
	GALVANIZED STEEL CUFF JOIN	50	VP06865	Connecting rubber accessories
	ALUMINIUM TUBE JOINT FITTING	50	VP07395	Connecting the accessories to the flexible hose Ø 50
	JOINT CUFF GALVANIZED STEEL	40	VP07370	Connecting two flexible hoses
	JOINT CUFF GALVANIZED STEEL	50	VP07369	
	DOUBLE "Y" SHAPED TEE GALVANIZED STEEL 70X40	40	VP07274	Connecting two extraction tubes to the inlet Ø 70
	DOUBLE "Y" SHAPED TEE GALVANIZED STEEL 70X50	50	VP07275	
	POLYPROPYLENE CUFF	40	VP03928	Flexible hose end joint - polythene EVA Accessory side cuff
	POLYTHENE HD CUFF	50	VP02367	
	30CM FLAT LANCE CHROMED STEEL	40	VP02296	Extracting liquids and dust from cracks
	30CM FLAT LANCE CHROMED STEEL	50	VP07177	Extracting liquids and dust from cracks
	60CM FLAT LANCE CHROMED STEEL	50	VP06866	
	ELBOW SHAPED FLAT LANCE - CHROMED STEEL	50	VP07067	Extracting liquids and dust from corners
	STEEL BRISTLE BRUSH	40	VP07239	Removing metal dust or greasy tars Removing dust
	STEEL BRISTLE BRUSH	40	VP07126	
	HORSEHAIR BRISTLE BRUSH	40	VP07241	
	HORSEHAIR BRISTLE BRUSH	40	VP07127	